

X-Loli

X-Loli Power Bank

2800mAh LG Lithium Battery

User Manual English



XDREAM

Features




Top-grade Cell: Built-in original LG lithium battery, made in Korea, more safe and reliable.

Personalization: Replace the body picture at ease.

Build-in USB Charging Plug: It provides the convenience of recharging. No extra cable is needed for charging or recharging.

Replace the Body Picture of X-Loli




Step1:

Follow the direction of the arrow to rotate and remove the bottom cap. Take out the main body of product.



Step2:

Roll the picture into a cylinder shape then insert into the protective shell.



Step3:


Insert the main body of product.

Step4:

Follow the direction of the arrow to rotate and lock the bottom cap.

- Warning: Double check the bottom cap is locked after you replace the picture. Bottom cap is unlocked or missing will cause the permanent damage.

Battery Life Extension




- | | |
|---------------|--------|
| ① iPhone 4(S) | ≈ 130% |
| ② iPhone 5 | ≈ 130% |
| ③ Samsung S3 | ≈ 90% |
| ④ Nokia 1020 | ≈ 90% |
| ⑤ HTC One | ≈ 80% |

Technical Data

Battery Capacity:	2800mAh
Battery Voltage:	3.7V
USB Input Voltage:	5V ---
USB Input Current:	600mA
USB Output Voltage:	5V ---
USB Output Current:	1000mA

Components



Blue indicator:


- Not in use: Light blue indicator shows battery has power when X-Loli is standby.
- In use: The blue indicator shows different brightness under different power conditions. The brighter, more power. The blue indicator goes out when X-Loli runs out of battery.
- When X-Loli has power, the blue indicator is always on, it's under standby mode. It only uses the internal natural wastage of battery. No extra waste.

Red Indicator:

- When charging X-Loli, the red indicator lights up.

Green Indicator:

- When X-Loli is fully charged, the green indicator lights up.



To Charge X-Loli

X-Loli does not have a dedicated adaptor and you can use any adapter with an USB interface or your computer's USB port to charge your X-Loli.



Use your fingers to pull out the USB charging plug and charging cable. Insert the USB charging plug into the USB port of your computer or an adaptor.



When charging is complete, hold the charging cable by one finger and push the USB charging plug by the other to restore the cable and plug.

- Make sure the USB charging plug is fully inserted into the USB port and the conducting strip touches the base of the USB port.




Correct to unplug



Incorrect to unplug

To Charge Personal Electronic Devices

Insert your personal electronic device's original charging cable into X-Loli's USB output port to charge your cellphone, digital camera or other mobile devices.



- X-Loli does not offer any charging connector or cable for your personal electronic devices. Suggest you use original charging cable of your electronic devices. Non-original charging cable or connector could be possible to damage your devices.
- All Indicators turn off while running out of battery.

Product Maintenance

When out of service for a long period, it is recommended to retain 30% of power and re-charge the X-Loli every two months.

Warning

Read all safety information below and operating instructions before using X-Loli to avoid possible

injury and damage to your device. We assume no responsibility for damage to charged devices due to improper operation of this product. Failure to follow these safety instructions could result in fire, electric shock, or other injury or damage.

- Use poor quality charging cable or adapter will cause damage to the safety of your life and property.
- The lithium-ion rechargeable battery used in X-Loli may present a risk of fire or chemical burn if mistreated. Do not disassemble, expose to heat above 212°F(100°C), including direct sunlight and fire. Misusing or incorrectly connecting this device may cause electric shock to users and damage equipment. When used correctly, lithium-ion rechargeable batteries provide a safe and dependable source of portable power.
- Do not drop or subject X-Loli to strong impacts.
- Do not operate X-Loli if it has received a sharp blow, been dropped or damaged in anyway.
- Do not expose X-Loli to moisture, water, rain, snow, or spray.
- X-Loli will experience a rise in temperature while in operation. Please make sure your device is exposed to air. Do not cover X-Loli with any item while it is operating.
- If X-Loli is overheating, swelling or moisturizing while in use, or there are any abnormal conditions, please stop using it immediately.
- Never attempt to repair or modify this power charger by yourself.
- Disassembling the main body of X-Loli may cause damage that is not covered under the warranty. Incorrect reassembly may result in shock or fire hazard.
- If X-Loli has been submerged in water, punctured, or subjected to a severe fall, do not use it.
- Never force a connector into a port, check for obstructions in the port, If the connector and port do not join with reasonable ease, they probably do not match. Make sure that the connector matches the port and that you have positioned the connector correctly in relation to the port.
- In the unlikely event of leakage or explosion, use sand or chemical fire extinguisher.
- It is recommended to fully charge X-Loli before your first use in order to extend its standby time.
- Never charge X-Loli unattended.
- Children or the elderly should use X-Loli under supervision.

XDREAM
WHAT XTENDS YOURSELF